Galanz

FREEZER/REFRIGERATOR
INSTRUCTION MANUAL
Model No.: GLF11UWEA16
GLF11US2A16

To ensure proper use of this appliance and your safety, please read the instruction manual completely before operating this appliance.

CONTENTS

Product Overview 1
Safety Warnings 2
Installation Instructions 3
Reversing the Door 4
Install the Handles 5
Operation Instructions 6
Packing and Moving 7
Maintenance 8
Defrost 8
Disconnecting the Appliance 9
User Notifications 9
Troubleshooting Tips 10
Specifications and Parameters 11
Packing List 12
Warranty 12

- Thank for purchasing our products and thank you for picking your confidence in us.
- Please read this manual carefully before using. Follow instructions and keep it for future reference.
- Please follow the operating instructions and safety notices in the manual.
- If you need to serve, do not fix it yourself or hand it to the after-sales service personnel who have not been authorized. Please contact the local authorized service center.

PRODUCT OVERVIEW

1. Control Display
2. Glass Shelves
3. Crisper Cover
4. Drawer
5. Switch
6. Door Bins

- The refrigerator you have purchased may look different from the image above as there could have been an improvement made.
- If you use the refrigerator for the first time, remove the adhesive tapes of the drawers. Remove the adhesive tapes before use.
- Do not apply too much force pushing or pulling the drawer or door bins as it could cause damage.

SAFETY WARNINGS

For your personal safety, please follow the instructions below:

1. The circuitry for refrigerator must be reliable. The area of cross-section of wire must be larger than 0.75mm². The power should be individual branch circuit. Incorrect circuit may cause fire. Please contact professional electrician for help.
2. The voltage and frequency of the product should be 110-120V~, Contact with the local maintenance station or retailer if the wire is damaged.
3. Disconnect power only by pulling the power plug out of the socket directly but not by the wire.
4. Do not damage the refrigerant circuit.
5. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
6. Children should be supervised to ensure that they do not play with the appliance.
7. Keep vent before opening, in the appliance enclosure or in the built-in structure, clear of obstruction.
8. Before you throw away your old refrigerator or freezer,
   - Take off the doors.
   - Leave the shelves in place so that children may not easily climb inside.
9. Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance. This appliance is intended to be used in household and similar applications such as:
   - staff kitchen areas in shops, offices and other working environments;
   - farm houses and by clients in hotels, motels and other residential type environments;
   - bed and breakfast type environments;
   - catering and similar non-retail applications.
10. Do not use electrical appliance inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
11. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

NOTICE:

1. When you pass from the container, do not put the plug, cord or, for it may cause fire or electric shock.
2. Do not touch water on the rear of the appliance, for it may cause malfunction or electric shock.
3. Do not put the flammable materials such as ether, benzene, LP gas and alcohol in the refrigerator.
4. Do not place bottled beverage in the freezer, so as to prevent breaking.
5. A recommended outlet is placed on the top of appliance which is magnetic heavy, or be touch wires. Electronic components may not work steadily if installed near the outlet. Please keep it which is safe or exposed to temperature and, eg, moisture, ambient and wiring.
6. The refrigerant of this product is R600a which is flammable. So, be cautious not to damage the cooling system during the transportation and installation.
7. DISPOSAL Do not dispose this product as unsorted municipal waste. Collection of such waste separately for special treatment is necessary.

INSTALLATION INSTRUCTIONS

1. This refrigerator should be located in a completely flat surface. Make sure the floor is strong enough to support the unit when fully loaded. Leave at least 1"(25.4mm) between the top of the appliance and the walls.
2. Choose a location which is not exposed to sunlight, high temperature or humid, as humidity may cause rust.
3. Turn out the bottom panel and level it with a.
4. The appliance can be adjusted by switching its two legs in the front. Use a wrench to turn the legs clockwise or counter-clockwise direction can raise or lower the leaning.
5. The location shall be firm and flat, an uneven surface may cause excessive noise and vibration. (If the caster may be exposed it the floor is soft tile, it's Put a sheet under the appliance to distribute the load and prevent if you wish to locate it on a carpet.
6. Make sure the adjustable legs are snug to the floor, and set the appliance down to ensure it is stay to keep the doors closed tightly.

REVERSING THE DOOR

You can choose to open your refrigerator by the right side or the left side.
Please contact professional electrician for help if you are not familiar.
Important safety warning: before doing any above-mentioned, disconnect the appliance.
In addition to the accessories packed, you will need:
Medium-sized cross screwdriver
Flat-blade screwdriver
Pencil

1. First, check to make sure the power is disconnected.
2. Open the upper door, and open the bottom door.

3. Remove the protective covers with a Phillips screwdriver through the back side, and save the protective covers.
4. Remove the 3 shelf-wrapping screws, and save them.
5. Push the top hinge forward, remove the door and save it aside.

6. Pry off and remove the cover over the screw holes on the left side of refrigerator housing. Attach covers on the right side. Screw in the screws.

7. Push the machine-drawn backward against the wall.
8. Disassemble the 2 fixed stands.
9. Disassemble the door from the hinge.
10. Assemble the bottom hinge on the other side of the machine.
11. Assemble the doors.
12. Assemble the 2 fixed stands to their on the other side.

INSTALL THE HANDLES

1. Unscrew the screws to loosen the fix screw and take out the handle components.
2. Take out the freezer door handle components.
3. Unscrew the freezer door handle and take it out.

4. Install the handle component on the right side.
5. Then screw tightly into the left screw hole.

OPERATION INSTRUCTIONS

1. Leave some space between items inside for air circulation.
2. Food should be kept in sealed package to prevent dry-out and odor.
3. Hot food should be cooled down before placing into the appliance. Otherwise, interior temperature and electronic consumption will increase.
4. Reducing the frequency of door opening can lower the electronic consumption.

INSTRUCTION FOR USAGE



5. When the door is opened, LED display will be ON. Press ⏻ for 3 seconds, the light of ⏻ will be shut, all the buttons will be locked. After the 3 minutes, temperature can be adjusted and the mode can be switched. Step of the 185. ⏻ Right will be turned on, the LED display will be automatic again.
6. After the start-up is in stock, Press ⏻ for 3 seconds, temperature display unit can be switched to Celsius or Fahrenheit. Right ⏻ 3 will be turned on according to the operation done mentioned above.
7. After the start-up is in stock, temperature can be adjusted by pressing ❄ in the freezer mode, temperature adjusted ranges are from -25°C to -15°C(-13°F to 5°F). In the fridge mode, temperature adjusted ranges are from 1°C to 7°C (33°F to 45°F).

4. After the start-up is in stock, Press ⏻ for 3 seconds, the light of ⏻ is turned on, all the buttons will be locked. After the 3 minutes, temperature can be adjusted and the mode can be switched. Step of the 185. ⏻ Right will be turned on, the LED display will be automatic again.
5. After the start-up is in stock, Press ⏻ for 3 seconds, temperature display unit can be switched to Celsius or Fahrenheit. Right ⏻ 3 will be turned on according to the operation done mentioned above.
6. After the start-up is in stock, temperature can be adjusted by pressing ❄ in the freezer mode, temperature adjusted ranges are from -25°C to -15°C(-13°F to 5°F). In the fridge mode, temperature adjusted ranges are from 1°C to 7°C (33°F to 45°F).

PACKING AND MOVING

1. Unpacking it, inspect and carry:
   - Please examine the position of each accessory of the appliance.
   - Please inspect, inspect the product and check carefully before transportation.
2. Do not lift up the door and the door handle during transportation.
3. When moving, the appliance can not be tilted over 45 degrees (the angle is the vertical direction). Please avoid strong vibration and bumping.

4. After the start-up is in stock, Fridge mode or freezer mode can be switched by pressing ⏻ for 3 seconds, the light of ⏻ will be shut, all the buttons will be locked. After FREEZER, the indicator light is on, freezer mode is switched.
5. After the refrigerator is in stock, quick cooling function is switched when ❄ is pressed. Quick Cooling function indicator light ❄ will be on. Press ❄ again, quick cooling mode can be exited manually.

P.S.:
- As for the Quick Cooling function, it can be only selected in the freezer mode, and it can not be selected in the fridge mode.
- In the Quick Cool Fridge mode, the freezer temperature can reach as low as -23°C(-9°F). Quick Cooling mode will be exited automatically when it is on for 24 hours continuously.

PACKING AND MOVING

1. Unpacking it, inspect and carry:
   - Please examine the position of each accessory of the appliance.
   - Please inspect, inspect the product and check carefully before transportation.
2. Do not lift up the door and the door handle during transportation.
3. When moving, the appliance can not be tilted over 45 degrees (the angle is the vertical direction). Please avoid strong vibration and bumping.

4. After the start-up is in stock, Fridge mode or freezer mode can be switched by pressing ⏻ for 3 seconds, the light of ⏻ will be shut, all the buttons will be locked. After FREEZER, the indicator light is on, freezer mode is switched.
5. After the refrigerator is in stock, quick cooling function is switched when ❄ is pressed. Quick Cooling function indicator light ❄ will be on. Press ❄ again, quick cooling mode can be exited manually.

P.S.:
- As for the Quick Cooling function, it can be only selected in the freezer mode, and it can not be selected in the fridge mode.
- In the Quick Cool Fridge mode, the freezer temperature can reach as low as -23°C(-9°F). Quick Cooling mode will be exited automatically when it is on for 24 hours continuously.

PACKING AND MOVING

1. Unpacking it, inspect and carry:
   - Please examine the position of each accessory of the appliance.
   - Please inspect, inspect the product and check carefully before transportation.
2. Do not lift up the door and the door handle during transportation.
3. When moving, the appliance can not be tilted over 45 degrees (the angle is the vertical direction). Please avoid strong vibration and bumping.

4. Take out the temperature and the moisture bar below in the direction of the arrow.

5. Take out the temperature and the moisture bar.

6. Put the connection terminal, use the screwdriver to remove the LED light board and replace it.

Note: If the LED lamp is abnormal, it should be replaced by professionals. Do not disassemble and replace it privately in order to avoid damage.

DEFROST

Defrosting of refrigerator will be executed automatically while the product is operating, and defrosting water will flow into the tray on the back of the refrigerator automatically, and evaporated by the heat of compressor, so there is no manual defrosting.

Warning! Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.

MAINTENANCE

The appliance should be maintained and cleaned frequently. For your safety, please follow the instructions of the content before the cleaning.

1. Interior maintenance
   Clean the interior of the appliance with a clean water or neutral detergent and rinse it with clean water. Wipe it dry with a soft piece of cloth.
2. Maintenance of door gasket
   It is easy to get damaged if the door gaskets are attached by the stain (food, sauce and tea, etc.) on them. It will ruin.
3. Color maintenance
   Wipe the surface with a piece of dry cloth, clean it with neutral detergent if necessary.
4. Lighting and its replacement
   When the refrigerating chamber door opens, the LED light turns on.
   When the light is damaged, please remove the lampshade first and then replace the LED light.
   The specific operations are shown in the following diagram:

5. Take out the lampshade and the installed screw seats.

6. Put the connection terminal, use the screwdriver to remove the LED light board and replace it.

Note: If the LED lamp is abnormal, it should be replaced by professionals. Do not disassemble and replace it privately in order to avoid damage.

DEFROST

Defrosting of refrigerator will be executed automatically while the product is operating, and defrosting water will flow into the tray on the back of the refrigerator automatically, and evaporated by the heat of compressor, so there is no manual defrosting.

Warning! Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.

DISCONNECTING THE APPLIANCE

After power failure, even in summer, the refrigerator can store food normally in several hours.

1. Disconnection during power failure
   After power failure, do not put additional food in the appliance and reduce the frequency of door opening. Ensure that the appliance is in a constant mode (no power failure) and normal, and put it in the top of the fridge.
2. Disconnection during vacation
   Please finish out the inside food and throw it in bags before start vacation, after disinfection. Close the door for 2-3 hours during vacation. Please lock up the food, prevent children from accidentally opening. Clean out the food and keep the door open for long time.
3. Stop using
   If the refrigerator is not going to be used for a long time, please unplug the outlet and clean up the appliance. The door should be kept open in order to prevent unpleasant smell caused by food breeding.

Attention! For personal safe reasons, do not stop the appliance in case of affecting to life. After unplugging the power, please throw out food 5 minutes before reuse time.

USER NOTIFICATIONS

1. Do not put food water on the refrigerator, as it will cause oxidation and malfunction.
2. Electronic component such as on/off button should be wiped dry.
3. Components such as soda powder, abrasive cleaning powder, detergent, chemical solvent, boiling water, etc. should not be used to clean the product, and be careful to avoid the refrigerator as they may damage the painted cover and plastic.
4. Never use damage the interior electronic component, so wipe it as soon as possible.
5. Please check the points before after maintenance:
   - Check the any damage or loss of the electronic wire.
   - Check the plug is put in the socket shuttle and properly.
   - Check the plug's connection is dry.

Warning! Please get rid of the parcel of the door before the disposal. Remove the door to prevent children from playing. Disconnect it, and do it by behalf of it in the environment.

TROUBLESHOOTING TIPS

1. The refrigerator does not work
   The plug may not be connected to the power supply, power cut or fused. Wiggle to be fine.
2. The refrigerator does not work efficiently as expected
   The door may be opened by heavy frost, or by warm temperature setting, or by frequently door operations.
3. It makes unusual noise
   It may be caused by an irregular floor or loose ground, pushing the appliance, or by abnormal noise from the compressor. Move or shift when necessary.
4. The compressor keeps working for a long period
   The environment temperature may be too high, The doors may be opened frequently or even they are left open, The compressor running time may be extended if the refrigerator is overloaded.
5. The freezer door keeps open
   Food with strong odour shall be packed tightly, before being put inside the appliance, Clean the door seals, The door may deformed, bent or whether the doors are put tightly for a long time.
6. Water leaks from the bottom of the refrigerator
   The drain hole is jammed, Please see a proper food inside it.
7. Heavy frost occurs on the rear of the appliance
   The door may be opened by heavy frost, Or the door is closed the product, Or it may be caused by the heavy environment moisture.
8. Switching mode from refrigerator to freezer, it takes time to lower the temperature to desired setting, A user wants to increase the temperature in a short time, It is advised to switch to the freezer mode.
9. In the freezer mode, food exposure may occur in the cabinet for a short time when the door is opened frequently, which causes the food to be frosted, It is operation is a secondly, Do not worry, since this is a normal phenomenon, Please wait from 20 to 30 seconds, then the door can be opened easily again!

The following options are normal operation.

1. Moisture may form due to the variation of the product during the humid season, just get it dried.
2. The flow of refrigerant through the pipelines will cause a noise.
3. It is normal that the sides of product get warm as a result of the cooling pipeline running.
4. The frame of the appliance will be warm during working to the defrost pipeline inside it.

Please check the points above first,
If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

SPECIFICATIONS AND PARAMETERS

Climate class		T
Electric shock protection type		I
Capacity(cu. ft) Freezer/Refrigerator		1/1
Voltage(V)		120
Frequency(Hz)		60
Current(A)		1.3
Voltage (BRAS)		6.48
Energy consumption (Kw/24h)	Freezer	354
	Refrigerator	249
Refrigerant		R600a/3.18oz
Weight(lbs)		128
Interior temperature (F)	Freezer	-8 ~ 5
	Refrigerator	33~45
Dimension(inch)	Width	23.50
	Depth	27.56
	Height	64.57

PACKING LIST

Parts	Number
Vegetable crisper	1pcs
Glass shelf	3pcs
Crisper glass cover	1pcs
Door bins	3pcs
Bottle guard	1pcs
Owner's manual	1 copy

Note: Products are subject to improve from time to time, any changes in parts without further notice.

Product Warranty

This warranty applies to products sold by Galanz Americas in the U.S. This warranty is in lieu of any other warranty and expressly applies to the individual product only.

Galanz product is warranted for one year starting purchase for defects in material and workmanship. **Please save your receipt as proof of purchase is required to make a warranty claim.** During this period, we will provide the replacement part of this product, a replacement on the equivalent, or repair on our discretion.

The warranty **cannot be transferred** through resale, including the resale through a third party unauthorized retailer and is only honored up on the original consumer purchaser upon purchase from an authorized retailer.

This warranty does not cover and further damages or losses caused by:

- Consumer misuse
- Abuse
- Accident, including the failure to clean and/or provide adequate regular maintenance as outlined in the user manual
- Commercial use
- Subjecting the product to any voltage outside the specified range
- Loss of parts
- The affixing of any attachments not provided with the product
- Accident, or
- Use in a manner not intended and outlined in the user manual

Any subsequent damages caused by the above listed conditions will not be covered and any claims determined to exist the above conditions will be denied. **All liability** is limited to the purchase price and does not include any:

- Food or stored extended warranties
- Other damages
- Time change (including postage to send required materials)
- Incidental and/or consequential damages associated with the product in question.

Every implied warranty, including any statutory warranty of merchantability or fitness for a particular purpose is disclaimed except to the extent prohibited by law, in which case such warranty is limited to the duration of this written warranty. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

If you have a claim under this warranty, please call our Customer Service number: **1-800-643-9730.**

For faster service, please have the **model** number, **serial** number, and **receipt** ready for the operator to assist you.