Galanz

FREEZER

INSTRUCTION MANUAL

Model No.:
GLF31UWED

To ensure proper use of this appliance and for your safety, please read the following instructions completely before operating this appliance.

CONTENTS

Names of the parts 1
Safety warnings 1
Installation instructions 2
Operation instructions 3
Packing and moving 4
Maintenance 4
Defrost 5
Disconnecting the appliance 5
User notifications 5
Troubleshooting tips 6
Specifications and parameters 7
Packing list 8

- Thank for purchasing our products and thank you for placing your confidence in us.
- Please read this manual carefully before using. Follow instructions and keep it for future references.
- Please follow the operating instructions and safety notices in the manual.
- If any trouble arises, do not fix it yourself or hand it to the after-sales service center which has not been authorized. Please contact the local authorized service center.

SAVE THIS INFORMATION FOR FUTURE REFERENCE

Galanz

Compact Freezer

Important notice: Please keep this appliance standing upright during transportation, as the unit must be kept on its side at any time. Please stand the appliance upright for at least 4 hours before using.

For all consumer questions or inquiries, please contact our Canada customer service line at 800-562-0735.

PARTS AND FEATURES

1. Temperature control knob

- The freezer you purchased may be in pictures), which maybe not completely consistent with the manual. However the functions and operating methods will not change. Please treat them as real.
- If you use the freezer for the first time, remove the adhesive tapes of the drawers, door and the inside of the freezer before using.
- Do not carry or push the drawers and the door forcibly, or they will cause damages.
- Adjusted the temperature control to a higher one you need access, which will save the energy consumption of the freezer and your money.
- Don't open the freezer door continually in such the normal working situation.
- Keep the combination of drawers, baskets and shelves of the freezer inconsistent with its original position.

SAFETY WARNINGS

To ensure your personal safety, please follow the instructions below:

1. The circuitry for freezer must be isolated. The area of cross section of wire must be 2.5mm² (copper wire) or 4mm² (aluminum wire) at least. Otherwise, the socket must be provided and replaced may cause fire and electric shock.
2. The voltage and frequency of the product should be 120V, 60Hz. Contact the local maintenance station or installer if the wire is damaged.
3. Disconnect power only by pulling the power plug out of the socket directly but not by the wire.
4. Do not damage the refrigerant circuit.
5. Children should be supervised to ensure they periodically not play with the appliance.
6. Keep away from operating, moving drawers/baskets in the unit. It will cause injury.
7. Before you throw away your old freezer,
   - Take off the doors.
   - Leave the shelves in place so that children may not easily climb inside.
8. Do not remove food or containers such as utensil and so on from the freezer. Remove the appliance. The appliance is intended to be used in household and similar applications such as:
   - staff kitchen areas in shops, offices and other working environments;
   - farm houses and by clients in hotels, motels and other residential type environments;
   - bed and breakfast type environments.
9. Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
10. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

NOTICE:

1. If gas leaks from its container, do not put the appliance on, or near open fire, or may cause explosion and fire accidents.
2. Don't splash water on the rear of the appliance, for it may cause malfunction and electric shock.
3. Don't store inflammable materials such as ether, benzene, LPG gas and gas in case the refrigerator.
4. Don't place bottled beverage in the freezer, so as to prevent breaking.

5. A container not to place objects on the top of appliance which is magnetic, heavy, or be filled with water, it likely to corrupt the body from rust internally, if water gets inside. Do not store objects which is easily corrodible in certain circumstances, such as medicines and vaccines.
6. The refrigerant of this product is R600a, is a **flammable** fluid. Please make sure to avoid damaging the refrigerant circuit and the pipelines of the product.

7. CAUTION - Do not operate electrical equipment within the refrigerated compartments of the appliance unless they are of the type recommended by the manufacturer.

INSTALLATION INSTRUCTIONS

1. The freezer should be placed on a completely flat surface, about 1.2"-1.97" (3-5cm) away from the wall to ensure good ventilation. Leave at least 11.81" (30 cm) between the top of the appliance and the shelf.
2. Choose a location which is not exposed to direct light and temperature of normal, and sufficiently ventilated area.
3. Protect out the rubber plug behind the shelf.
4. The product is heavy and cumbersome, **do not** attempt to move it by yourself. Please ask for help or use a dolly. Be careful not to damage the floor.
5. The appliance should not be tilted and the unfavorable position may cause noise and failure.
   (1) Adjust the front feet to level the body of the freezer.
   (2) If it is uneven, lower the adjustable feet by turning the feet anticlockwise if you need to fasten it in a certain.

6. Allow the appliance to stand for at least 4 hours before plugging in.
   Caution: Do not plug in the appliance during the above steps.

OPERATION INSTRUCTIONS

PLACEMENT OF FOOD

1. There should be enough air to allow space between stored food for air circulation.
2. Food should be kept in sealed packages to avoid becoming dry or odd odors.
3. Hot food should be cooled down before placing into the freezer, so as to keep the inner temperature and decrease consumption and running times.
4. Reduce the frequency of door opening can effectively help lower the electronic consumption.

Warning! Do not use any electronic equipment inside the appliance.

INSTRUCTION FOR USAGE

The temperature of freezer can be controlled manually with the dial. The number 1 is the warmest and 5 is the coldest. Choose the appropriate temperature according to your need. Turn to the number 0 to turn off the freezer. Turn to the setting number as desired. Freezer will turn off at setting.

PACKING AND MOVING

1. Unpacking, inspecting and damage notification
   Please remove all the protective sheet accessory of the appliance carefully. Inspect the product and check if there is any damage during transportation.
2. Do not lift or drag the door or the door handle during transportation.
3. When moving, the appliance cannot be placed over 45 degrees. Use gentle force when moving freezers. Please avoid strong vibration and impact.

MAINTENANCE

The freezer should be clean interior and exterior frequently. For your safety, cut the plug out of the electrical outlet before cleaning.

1. Exterior maintenance
   Wipe the surface of the freezer with clean water or a neutral cleaning solution and rinse with a dry cloth.
2. Maintenance of door gaskets
   Keep door gaskets clean, wipe them with mild, damp cloth and dried immediately from the gaskets.
3. Drain maintenance
   Wipe with a dry cloth and clean with neutral cleaning solution if necessary.

DEFROST

Defrost Procedures: Remove all food items from the freezer, take out all drawers and baskets, and unplug the cord from the electrical outlet. Keep the freezer door open. Allow the frost to melt. Wipe the inside of the freezer with water or a mild, non-abrasive soap with a dry cloth. Wipe the inside of the freezer with water or a mild, non-abrasive soap with a dry cloth. Keep door open to prevent any unwanted odors.

Warning! Do not use any other equipment or method to push the defrost process if they are not recommended by factory.

DISCONNECTING THE FREEZER

After a power failure the freezer can store food normally for several hours, as the cold stored in the evaporators can maintain low temperature.

1. Long period disconnection
   After power outage, do not put additional food items into the freezer, keep the door closed as much as possible to preserve the stored food properly for longer periods of time.
2. Disconnecting the freezer for long periods of time.
   Remove all food items from the freezer. Remove the plug from the electrical outlet. Clean the freezer thoroughly. Wipe the inside of the freezer with a dry cloth and leave the door open to avoid mold and odor.

3. Storing the freezer for long periods of time.
   Follow the steps in "Disconnecting the freezer" above. Tape the same defrost procedure as above. The freezer door should not be taped to prevent any unpleasant odors from remaining in the freezer.

Warning! In a commercial location, do not stop the appliance in case of affecting the food stored inside. When unplugging the power, please leave at least 5 minutes before reconnection.

USER NOTIFICATIONS

1. Do not put water on the freezer, as it may cause condensation and moisture. Electronic components such as circuit boards could be impaired or fail.
2. Do not use sharp objects to remove frost from the freezer. Use plastic scrapers, chemical fluids, thinner, alcohol and gasoline are prohibited for cleaning. Do not be used to clean the freezer as they may damage the painted cover and plastics.
3. Never can damage the interior plastic component, as wipe it as warm as much as possible.

4. Please check the points below after maintenance.
   (1) Is the wiring damaged? Are all the electrical wires tight?
   (2) Can the plug be put in the socket tightly and smoothly?
   (3) Are there any loosening components?

Warning! Please get rid of the gaskets of the door before the disposal. The disposed appliance shall be first handled by professional staff, as it may be harmful to the environment.

TROUBLESHOOTING TIPS

1. The freezer does not work
   It may not be connected to the power supply, e.g., power cut or fuses, voltage is too low, etc.
2. The freezer does not work efficiently or overspeed
   The door may be caused by heavy frost, dirty items temperature setting or by frequent door openings.
3. It makes an loud noise
   It is normal that there is noise vibration or noise caused by the appliance, or by installation between the appliance and other ancillary objects.
4. The compressor keeps working for a long period
   The ambient temperature may be too high. The appliance may be opened frequently or warm items are put in. The compressor is running in its 24-7 state may be caused by the heavy load of temperature.
5. Pungent odour
   Food with strong odour should be packed tightly before being put inside the appliance, or the odour may be absorbed by other products. Remove all unwanted items and dirt only for long time.
6. Water flows from the bottom of the freezer
   The drain hole is plugged up. Please clean up and it will be ok.
7. Heavy frost occurs on the rear of the appliance
   The door is not closed properly or the door gasket is dirty, worn or has caused this problem. Or it may be caused by too many models as above.

The following cases are not malfunction

1. Moisture may form on the outside of the product during the humid season, just pat it dry.
2. The liquid refrigerant through the pipelines can cause a noise.
3. It is normal that the sides of product get warm as a result of the working pipeline warmly.

5. The failure of the appliance will be solved in during warranty by the dedicated personnel from Galanz.

Please check the points above first.
If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

SPECIFICATIONS AND PARAMETERS

Model		GLF31UWED
Climate class		T
Electric shock protection type		I
Capacity (cu.ft)	Freezer	3.31
	Refrigerator	-
Voltage (V)		120
Frequency (Hz)		60
Current (A)		0.35
Volts (dB(A))		≤ 42
Energy consumption (kWh/24H)		0.49
Refrigerant		R600a (35g)
Weight (Lbs)		60.64
Ambient temperature (°C)	Freezer	+43
	Refrigerator	-
Dimension (in)	Width	21.69
	Depth	23.43
	Height	33.15

Limited Warranty

This warranty applies to products purchased and used in Canada. This is the only express warranty for this product and is in lieu of any other warranty.

This product is warranted to be free from defects in material and workmanship for a period of one (1) year from the date of original purchase, except as noted below. During this period, we will repair or replace this product at our option.

This warranty extends only to the original consumer purchaser and does not cover a defect resulting from abuse, misuse, neglect, improper repair or alteration or failure to operate the product in accordance with the instructions, nor for commercial purposes, or any use not in conformity with the printed literature.

We make no express warranty, and no implied warranty (except to the extent of applicable law) shall apply after the period of time from the date of original purchase specified above. **Implied warranties, including any statutory warranty of merchantability or fitness for a particular purpose, is disclaimed except to the extent prohibited by law, in which case such warranty is limited to the duration of this written warranty.** This warranty gives you specific legal rights. You may have other legal rights that vary depending on where you live. Some states do not allow limitations on implied warranties or exclusion of incidental or consequential damages, so the foregoing limitations may not apply to you.

If you have a question on this warranty, please call our CUSTOMER SERVICE NUMBER.
For faster service please have model, serial, and type numbers ready for operator to assist you.

CUSTOMER SERVICE NUMBER
In Canada: 8005620735

KEEP THIS NUMBER FOR FUTURE REFERENCE!
Warrantor: Zhongshan Galanz Consumer
Electric Appliances Co., Ltd. Guangdong 528429